


Installation guide

To install the tool, open your Allmenu and navigate to Allplans STD-directory.



Copy the two directories from the download (Library and PythonPartsScripts) into the STD-directory.

The tool will now appear in your library under “Office – SOIL-PARTS – BIM2Excel”

